
# INSTRUCTIONS FOR: W3012 / W3015 / W3018 / W3612 / W3615 / W3618 W361224 / W361524 / W361824 / W361227 / W361527 / W361827



#### [ASSEMBLY INSTRUCTIONS]

#### Getting Started:

Prepare protection layer/screwdriver/micro pin-nail.


Apply glue&micro pin-nail to joint as needed.

- STEP 1: Joint side panel with back panel
- STEP 2: Joint side panel with back panel and attacing top panel for giving support
- STEP 3: Joint back panel with side panel and back panel
- STEP 4: Attach frame on
- STEP 5: Attach door onto the frame and adjust the cover-space

NO.	DESCRIPTION	QTY
Α	Side Panel	2
В	Back Panel	1
С	Top&Bottom Panel	2
D	Face Frame	1
E	Cabinet Doors	2

<u></u>					3				
HARDWARE L	ISTS								
PICTURE	QTY	DESCRIPTION	PICTURE	QTY	DESCRIPTION	PICTURE	QTY	DESCRIPTIO	N
1" flat head screw	8	1" Flat Head Screw for Carcass	3/4" round head screw	4	3/4" Round Head Screw				
Cleat	14	Cleat	1 1/2" hinge	4	1 1/2" Softclose Hinge				
9/16" round head screw	56	9/16" Round Head Screw							
Bunper	4	Bumper							

## INSTRUCTIONS FOR: MO3030 / MO3036 / MO3042



#### [ ASSEMBLY INSTRUCTIONS ]

#### Getting Started:

Prepare protection layer/screwdriver/micro pin-nail. Apply glue&micro pin-nail to joint as needed.

STEP 1: Joint top panel with back panel

STEP 2: Joint side panel with back panel

STEP 3: Joint bottom panel and middle panel with side panel

STEP 4: Attach rame on


STEP 5: Attach door onto the frame and adjust the cover-space

NO.	DESCRIPTION	QTY
Α	Top&Bottom Panel	2
В	Back Panel	1
С	Side Panel	2
D	Bottom Panel	2
E	Face Frame	1
F	Cabinet Doors	2

HARDWARE L	ISTS							
PICTURE	QTY	DESCRIPTION	PICTURE	QTY	DESCRIPTION	PICTURE	QTY	DESCRIPTION
1" flat head screw	12	1" Flat Head Screw for Carcass	3/4" round head screw	4	3/4" Round Head Scre			
Cleat	19	Cleat	1 1/2" hinge	4	1 1/2" Softclose Hinge			
9/16" round head screw	76	9/16" Round Head Screw						
Bumper	4	Bumper						

#### INSTRUCTIONS FOR:

U188424 / U189024 / U189624 / U248424 / U249024 / U249624 / U308424 / U309024 / U309624 U188427 / U189027 / U189627 / U248427 / U249027 / U249627 / U308427 / U309027 / U309627



#### [ ASSEMBLY INSTRUCTIONS ]

#### Getting Started:

Prepare protection layer/screwdriver/micro pin-nail. Apply glue&micro pin-nail to joint as needed.

STEP 1: Joint side panel with top panel

STEP 2: Joint side panel with middle&bottom panel

STEP 3: Joint side panel with middle&bottom panel

STEP 4: Joint side panel with middle&bottom panel

STEP 5: Attach frame on


STEP 6: Put on the adjustable shelves

STEP 7: Attach door onto the frame and adjust the cover-space

NO.	DESCRIPTION	QTY
Α	Side Panel	2
В	Top&Bottom Panel	3
С	Toe Kick	1
D	Face Frame	1
E	Back Panel	1
F	Cabinet Doors	1or2
G	Cabinet Doors	1or2
Н	Adjustable Shelf	5

HARDWARE L	ISTS							
PICTURE	QTY	DESCRIPTION	PICTURE	QTY	DESCRIPTION	PICTURE	QTY	DESCRIPTION
1" flat head screw	6	1" Flat Head Screw for Carcass	Bumper	4	Bumper		4	3/4" Round Head Screw
© © Oleat	14	Cleat	3/4" round head screw	5	3/4" Round Head Screw			
9/16" round head screw	56	9/16" Round Head Screw	1 1/2° hinge	5	1 1/2" Softclose Hinge			
	20	Shelf Clip						

### INSTRUCTIONS FOR: VKD36



#### [ ASSEMBLY INSTRUCTIONS ]

#### Getting Started:

Prepare protection layer/screwdriver/micro pin-nail. Apply glue&micro pin-nail to joint as needed.

STEP 1: Joint side panel with back panel

STEP 2: Joint side panel with back panel

STEP 3: Attach frame on and toekick board

STEP 4: Attach the metal triangle on the top corner

STEP 5: Joint the drawer together, then install the drawer guide


STEP 6: Fix drawer head on the drawer front and adjust the cover-space

PARTS L	ISTS	57.75
NO.	DESCRIPTION	QTY
Α	Side Panel	2
В	Back Panel	1
С	Face Frame	1
D	Drawer Head	1
E	Drawer Box Bottom	1
F	Drawer Box Front&Back	2
G	Drawer Box Side	2

HARDWARE L	ISTS							
PICTURE	QTY	DESCRIPTION	PICTURE	QTY	DESCRIPTION	PICTURE	QTY	DESCRIPTION
1° flat head sorew	8	1" Flat Head Screw for Metal Triangle	Delicione states	1	18" Selfclose Slide			
	4	Metal Triangle	1" round head screw	4	1" Round Head Screw			
(S) (S) (C) (C) (C) (C) (C) (C) (C) (C) (C) (C	4	Cleat	Bumper	4	Bumper			
9/16" round head screw	16	9/16" Round Head Screw						

## INSTRUCTIONS FOR: VS24 / VS27 / VS30 / VS33 / VS36 /

#### SB24 / SB27 / SB30 / SB33 / SB36 / SB39



#### [ ASSEMBLY INSTRUCTIONS ]

#### Getting Started:

Prepare protection layer/screwdriver/micro pin-nail. Apply glue&micro pin-nail to joint as needed.


- STEP 1: Joint side panel with back panel
- STEP 2: Joint bottom panel with side panel
- STEP 3: Joint side panel with bottom&back panel
- STEP 4: Attach frame on and toekick board
- STEP 5: Attach the metal triangle on the top corner and put on the adjustable shelf
- STEP 6: Attach door&drawer head onto the frame and adjust the cover-space

#### PARTS LISTS DESCRIPTION QTY Back Panel Α 1 В Side Panel 2 С Top&Bottom Panel 1 Toekick D 1 E Face Frame 1 F 2 **Cabinet Doors** G Drawer Head 1

HARDWARE L	ISTS							
PICTURE	QTY	DESCRIPTION	PICTURE	QTY	DESCRIPTION	PICTURE	QTY	DESCRIPTION
1" flat head screw	8	1" Flat Head Screw for Metal Triangle	9/16" round head screw	44	9/16" Round Head Screw			
	4	Metal Triangle	Burper	4	Bumper			
1" flat head screw	3	1" Flat Head Screw for Carcass	3/4" round head screw	4	3/4" Round Head Screw			
Cleaf	11	Cleat	1 1/2" hinge	4	1 1/2" Softclose Hinge			

#### INSTRUCTIONS FOR:

W2430 / W2730 / W3030 / W3330 / W3630 / W2430GD W2436 / W2736 / W3036 / W3336 / W3636 / W2436GD W2442 / W2742 / W3042 / W3342 / W3642 / W2442GD



#### [ASSEMBLY INSTRUCTIONS]

#### Getting Started:

Prepare protection layer/screwdriver/micro pin-nail. Apply glue&micro pin-nail to joint as needed.

STEP 1: Joint side panel with back panel

STEP 2: Joint top panel with side panel

STEP 3: Joint bottom panel with side panel

STEP 4: Attach frame on


STEP 5: Put on the adjustable shelves

STEP 6: Attach door onto the frame and adjust the cover-space

NO.	DESCRIPTION	QTY
Α	Side Panel	2
В	Back Panel	1
С	Top&Bottom Panel	2
D	Face Frame	1
E	Adjustable Shelf	2 or 3
F	Cabinet Doors	2

HARDWARE L	ISTS			900			70 70	
PICTURE	QTY	DESCRIPTION	PICTURE	QTY	DESCRIPTION	PICTURE	QTY	DESCRIPTION
1" flat head screw	6	1" Flat Head Screw for Carcass	Burper	4	Bumper			
Cleat	14	Cleat	3/4" round head screw	4	3/4" Round Head Screw			
9/16" round head screw	56	9/16" Round Head Screw	1 1/2" hhge	4	1 1/2" Softclose Hinge			
	8	Shelf Clip						

# INSTRUCTIONS FOR: W3021 / W3024 / W3621 / W36244 W362124 / W362424 / W362127 / W362427



### [ ASSEMBLY INSTRUCTIONS ]

#### Getting Started:

Prepare protection layer/screwdriver/micro pin-nail. Apply glue&micro pin-nail to joint as needed.

STEP 1: Joint side panel with back panel

STEP 2: Joint top panel with side panel

STEP 3: Joint bottom panel with side panel

STEP 4: Attach frame on


STEP 5: Put on the adjustable shelves

STEP 6: Attach door onto the frame and adjust the cover-space

NO.	DESCRIPTION	QTY
Α	Side Panel	2
В	Back Panel	1
С	Top&Bottom Panel	2
D	Face Frame	1
E	Adjustable Shelf	1
F	Cabinet Doors	2

100								3/4 (4			
HARDWARE L	HARDWARE LISTS										
PICTURE	QTY	DESCRIPTION	PICTURE	QTY	DESCRIPTION	PICTURE	QTY	DESCRIPTION			
1" flat head screw	8	1" Flat Head Screw for Carcass	Burper	4	Bumper						
© © Oleat	14	Cleat	3/4" round head screw	4	3/4" Round Head Screw						
9/16" round head screw	56	9/16" Round Head Screw	1 1/2" hhqe	4	1 1/2" Softclose Hinge						
	4	Shelf Clip									

#### INSTRUCTIONS FOR: AW1230 / AW1236 / AW1242



#### [ASSEMBLY INSTRUCTIONS]

#### Getting Started:

Prepare protection layer/screwdriver/micro pin-nail. Apply glue&micro pin-nail to joint as needed.

STEP 1: Joint top&bottom panel with side panel

STEP 2: Attach left side panel STEP 3: Attach the frame


STEP 4: Attach door to the frame and adjust the cover-space

STEP 5: Put on the adjustable shelves

NO.	DESCRIPTION	QTY
Α	Right Side Panel	1
В	Top&Bottom Panel	2
С	Left Side Panel	1
D	Face Frame	1
E	Cabinet Doors	1
F	Adjustable shelf	2 or 3

(1)										
HARDWARE L	HARDWARE LISTS									
PICTURE	QTY	DESCRIPTION	PICTURE	QTY	DESCRIPTION	PICTURE	QTY	DESCRIPTION		
Oleat	8	Cleat	3/4" round head screw	2	3/4" Round Head Scre					
9/16" round head screw	32	9/16" Round Head Screw	1 1/2" hinge	2	1 1/2" Softclose Hinge					
	8 or 12	Shelf Clip								
Bumper	2	Bumper								

## INSTRUCTIONS FOR: B30/B33 / B36 / B42



#### [ ASSEMBLY INSTRUCTIONS ]

#### Getting Started:

Prepare protection layer/screwdriver/micro pin-nail. Apply glue&micro pin-nail to joint as needed.

STEP 1: Joint side panel with back panel

STEP 2: Joint bottom panel with side panel

STEP 3: Joint side panel with bottom & back panel

STEP 4: Attach frame on and toekick board

STEP 5: Joint the drawer together, then install the drawer guide.

STEP 6: Attach the wood block on the top corner and


put on the adjustable shelf

STEP 7: Fix drawer head on the drawer front, attach door onto the frame and adjust the cover-space

10000		
NO.	DESCRIPTION	QTY
Α	Back Panel	1
В	Side Panel	2
С	Top&Bottom Panel	1
D	Toe Kick	1
E	Face Frame	1
F	Drawer Box Front&Back	4
G	Drawer Box Side	4
Н	Drawer Box Bottom	2
1	Adjustable Shelf	1
J	Drawer Head	2
К	Cabinet Doors	2

HARDWARE L	HARDWARE LISTS									
PICTURE	QTY	DESCRIPTION	PICTURE	QTY	DESCRIPTION	PICTURE	QTY	DESCRIPTION		
1" flat head screw	8	1" Flat Head Screw for Metal Triangle	9/16" round head screw	44	9/16" Round Head Screw	Bumper	12	Bumper		
	4	Metal Triangle		4	Shelf Clip	3/4" round head screw	4	3/4" Round Head Screw		
1" flat head screw	4	1" Flat Head Screw for Carcass	Francisco desc	2	Selfclose Slider	1 1/2" hings	4	1 1/2" Softclose Hinge		
(S) (S) (Cleaf	11	Cleat		8	1" Round Head Screw					

## INSTRUCTIONS FOR: BBC36 / BBC42



### [ ASSEMBLY INSTRUCTIONS ]

#### Getting Started:

Prepare protection layer/screwdriver/micro pin-nail. Apply glue&micro pin-nail to joint as needed.

STEP 1: Joint side panel with back panel

STEP 2: Joint bottom panel with side panel

STEP 3: Joint side panel with bottom&back panel

STEP 4: Attach frame on and toekick board

STEP 5: Joint the drawer together, then install the drawer guide


STEP 6: Attach the metal triangle on the top corner, and put on the adjustable shelf


STEP 7: Fix drawer head on the drawer front and attach door onto the frame and adjust the cover-space

_			
	NO.	DESCRIPTION	QTY
	Α	Back Panel	1
	В	2	
	С	Top&Bottom Panel	1
	D	Toe Kick	1
	E	Face Frame	1
	F	Drawer Box Front&Back	2
V	G	Drawer Box Side	2
	Н	Drawer Box Bottom	1
	1	Adjustable Shelf	1
	J	Drawer Head	1
	K	Cabinets Door	1

HARDWARE L	HARDWARE LISTS									
PICTURE	QTY	DESCRIPTION	PICTURE	QTY	DESCRIPTION	PICTURE	QTY	DESCRIPTION		
1" flat head screw	8	1" Flat Head Screw for Metal Triangle	9/16" round head screw	44	9/16" Round Head Screw	Bumper	6	Bumper		
	4	Metal Triangle		4	Shelf Clip	3/4" round head screw	2	3/4" Round Head Screw		
1° flat head screw	5	1" Flat Head Screw for Carcass	Francisco das	1	Selfclose Slider	1 1/2" hings	2	1 1/2" Softclose Hinge		
(S) (S) (C) (C) (C) (C) (C) (C) (C) (C) (C) (C	11	Cleat	1" round head screw	4	1" Round Head Screw					

### INSTRUCTIONS FOR: BEC24





#### [ ASSEMBLY INSTRUCTIONS ]

#### Getting Started:

Prepare protection layer/screwdriver/micro pin-nail. Apply glue&micro pin-nail to joint as needed.

STEP 1: Joint two side panel together

STEP 2: Attach top panel

STEP 3: Attach bottom panel

STEP 4: Attach teokick on

STEP 5: Attach frame on


STEP 6: Put on the adjustable shevles

STEP 7: Attach door onto the face frame and adjust the cover-space

#### PARTS LISTS NO. DESCRIPTION QTY Α Side Panel 1 В Side Panel 1 C Top&Bottom Panel 2 Toe Kick D 2 Е Face Frame 2 F Adjustable Shelf 2 G Cabinet Doors 2

HARDWARE L	ISTS							
PICTURE	PICTURE QTY DESCRIPTION		PICTURE	QTY	DESCRIPTION	PICTURE	QTY	DESCRIPTION
1" flat head screw	5	1" Flat Head Screw for Metal Triangle	Burper	4	Bumper		2	Metal Angle
(i) (ii) (iii) (ii	18	Cleat	3/4" round head screw	4	3/4" Round Head Screw			
9/16" round head screw	78	9/16" Round Head Screw	1 1/2" hinge	4	1 1/2" Softclose Hinge			
	12	Shelf Clip	135° angle	3	135 Degree Angle			

## INSTRUCTIONS FOR: BWB18



#### [ ASSEMBLY INSTRUCTIONS ]

#### Getting Started:

Prepare protection layer/screwdriver/micro pin-nail. Apply glue&micro pin-nail to joint as needed.

STEP 1: Joint side panel with back panel

STEP 2: Joint bottom panel with side panel

STEP 3: Joint side panel with bottom&back panel

STEP 4: Attach frame on and teokick board

STEP 5: Attach the metal triangle on the top corner

STEP 6: Joint the drawer together, then install the drawer guide


TEP 0. Joint the drawer together, then install the drawer guid

STEP 7: Fix drawer head on the drawer front and adjust the cover-space

NO.	DESCRIPTION	QTY
Α	Back Panel	1
В	Side Panel	2
С	Top&Bottom Panel	1
D	Toe Kick	1
E	Face Frame	1
F	Drawer Box Front&Back	4
G	Drawer Box Side	4
Н	Drawer Box Bottom	2
1	Drawer Head	1
J	Cabinet Doors	1

HARDWARE L	HARDWARE LISTS									
PICTURE	QTY	DESCRIPTION	PICTURE	QTY	DESCRIPTION	PICTURE	QTY	DESCRIPTION		
1" flat head screw	8	1" Flat Head Screw for Metal Triangle	9/16" round head screw	40	9/16" Round Head Screw					
	4	Metal Triangle	3/4" round head screw	2	Selfclose Slider					
1" flat head screw	2	1" Flat Head Screw for Carcass	1" round head screw	8	1" Round Head Screw					
(S) (S) (Clear	10	Cleat	Bumper	8	Bumper					

## INSTRUCTIONS FOR: 0338424 / 0339024 / 0339624 / 0338427 / 0339027 / 0339627



### [ ASSEMBLY INSTRUCTIONS ]

#### Getting Started:

Prepare protection layer/screwdriver/micro pin-nail. Apply glue&micro pin-nail to joint as needed.

STEP 1: Joint side panel with top panel

STEP 2: Joint back panel with side panel

STEP 3: Joint side panel with middle&bottom panel STEP 4: Joint side panel with middle&bottom panel

STEP 5: Fix shelf board

STEP 6: Attach frame on and toekick board


STEP 7: Joint the drawer together, then install the drawer guide

STEP 8: Attach door&drawer head onto the frame and

adjust the cover-space

NO.	DESCRIPTION	QTY			
Α	Side Panel	2			
В	Top&Bottom Panel	3			
С	Back Panel	1			
D	D Face Frame				
E	E Toe Kick				
F	Drawer Box Front&Back	6			
G	Drawer Box Side	6			
Н	Drawer Box Bottom	3			
1	Drawer Head	3			
J	Cabinet Doors	2			
K	Adjustable Shelf	2			

HARDWARE L	HARDWARE LISTS									
PICTURE	QTY	DESCRIPTION	PICTURE	QTY	DESCRIPTION	PICTURE	QTY	DESCRIPTION		
1" flat head screw	22	1" Flat Head Screw for Carcass	Takkan dite	44	Selfclose Slider	1 1/2" hinge	4	1 1/2" Softclose Hinge		
(S) (S) (Cleaf	17	Cleat	1" round head screw	12	1" Round Head Screw					
9/16" round head screw	68	9/16" Round Head Screw	Bumper	16	Bumper					
	4	Shlef Clip	3/4" round head screw	12	3/4" Round Head Screw					



#### [ASSEMBLY INSTRUCTIONS]

#### Getting Started:

Prepare protection layer/screwdriver/micro pin-nail. Apply glue&micro pin-nail to joint as needed.

STEP 1: Joint top&bottom with side panel

STEP 2: Joint middle&bottom panel with side panel


STEP 3: Joint back panel with side panel

	NO.	DESCRIPTION	QTY
(B)	Α	Side Panel	1
	В	Top&Bottom Panel	2
	С	Adjustable Shelf	2 or 3
	D	Side Panel	1
			2

HARDWARE L	HARDWARE LISTS										
PICTURE	QTY	DESCRIPTION	PICTURE	QTY	DESCRIPTION	PICTURE	QTY	DESCRIPTION			
1" flat head screw	19	1" Flat Head Screw for Carcass									
Dowel	19 or 24	Dowel									

#### INSTRUCTIONS FOR:

#### **SB42**



#### [ ASSEMBLY INSTRUCTIONS ]

#### Getting Started:

Prepare protection layer/screwdriver/micro pin-nail. Apply glue&micro pin-nail to joint as needed.

STEP 1: Joint side panel with back panel

STEP 2: Joint bottom panel with side panel

STEP 3: Joint side panel with bottom&back panel

STEP 4: Attach frame on and toekick board

STEP 5: Attach the metal triangle on the top corner


STEP 6: Fix door&drawer head onto the frame and adjust the cover-space

NO.	QTY					
Α	A Back Panel					
В	Side Panel	2				
С	Top&Bottom Panel	1				
D	Toekick	1				
E	Face Frame	1				
F	Drawer Head	2				
F	Cabinet Doors	2				
		+				

HARDWARE L	HARDWARE LISTS											
PICTURE	QTY	DESCRIPTION	PICTURE	QTY	DESCRIPTION	PICTURE	QTY	DESCRIPTION				
1" flat head screw	8	1" Flat Head Screw for Metal Triangle	9/16" round head screw	44	9/16" Round Head Screw							
	4	Metal Triangle	Bumper	4	Bumper							
1" flat head screw	4	1" Flat Head Screw for Carcass	3/4" round head screw	4	3/4" Round Head Screw							
© © O	11	Cleat	1 1/2" hinge	4	1 1/2" Softclose Hinge	_						

#### INSTRUCTIONS FOR:

W0930 / W1230 / W1530 / W1830 / W2130 / W1530GD W0936 / W1236 / W1536 / W1836 / W2136 / W1536GD W0942 / W1242 / W1542 / W1842 / W2142 / W1542GD



#### [ ASSEMBLY INSTRUCTIONS ]

#### Getting Started:

Prepare protection layer/screwdriver/micro pin-nail. Apply glue&micro pin-nail to joint as needed.

STEP 1: Joint side panel with back panel

STEP 2: Joint top panel with side panel

STEP 3: Joint bottom panel with side panel

STEP 4: Attach frame on


STEP 5: Put on the adjustable shelves

STEP 6: Attach door onto the frame and adjust the cover-space

NO.	DESCRIPTION	QTY
Α	Side Panel	2
В	Back Panel	1
С	Top&Bottom Panel	2
D	Face Frame	1
E	Adjustable Shelf	2 or 3
F	Cabinet Doors	1

<u> </u>								24.8				
HARDWARE L	HARDWARE LISTS											
PICTURE	QTY	DESCRIPTION	PICTURE	QTY	DESCRIPTION	PICTURE	QTY	DESCRIPTION				
1° flat head screw	4	1" Flat Head Screw for Carcass	Burrper	2	Bumper							
© © Cleat	10	Cleat	3/4" round head screw	2	3/4" Round Head Screw							
9/16" round head screw	40	9/16" Round Head Screw	1 1/2" hinge	2	1 1/2" Softclose Hinge							
	8	Shelf Clip										

# INSTRUCTIONS FOR: W3012 / W3015 / W3018 / W3612 / W3615 / W3618 W361224 / W361524 / W361824 / W361227 / W361527 / W361827



#### [ASSEMBLY INSTRUCTIONS]

#### Getting Started:

Prepare protection layer/screwdriver/micro pin-nail.


Apply glue&micro pin-nail to joint as needed.

- STEP 1: Joint side panel with back panel
- STEP 2: Joint side panel with back panel and attacing top panel for giving support
- STEP 3: Joint back panel with side panel and back panel
- STEP 4: Attach frame on
- STEP 5: Attach door onto the frame and adjust the cover-space

NO.	DESCRIPTION	QTY
Α	Side Panel	2
В	Back Panel	1
С	Top&Bottom Panel	2
D	Face Frame	1
E	Cabinet Doors	2

					1							
HARDWARE L	HARDWARE LISTS											
PICTURE	QTY	DESCRIPTION	PICTURE	QTY	DESCRIPTION	PICTURE	QTY	DESCRIPTION				
1" flat head screw	8	1" Flat Head Screw for Carcass	3/4" round head screw	4	3/4" Round Head Screw							
Cleaf	14	Cleat	1 1/2" hinge	4	1 1/2" Softclose Hinge							
9/16" round head screw	56	9/16" Round Head Screw										
Bumper	4	Bumper										

## INSTRUCTIONS FOR: WBC2730 / WBC2742



### [ ASSEMBLY INSTRUCTIONS ]

#### Getting Started:

Prepare protection layer/screwdriver/micro pin-nail. Apply glue&micro pin-nail to joint as needed.

STEP 1: Joint side panel with back panel

STEP 2: Joint top panel with side panel

STEP 3: Joint bottom panel with side panel

STEP 4: Attach frame on


STEP 5: Put on the adjustable shelves

STEP 6: Attach door onto the frame and adjust the cover-space

NO.	DESCRIPTION	QTY
А	Side Panel	2
В	Back Panel	1
С	Top&Bottom Panel	2
D	Face Frame	1
E	Adjustable Shelf	2
F	Cabinet Doors	1

HARDWARE L	HARDWARE LISTS											
PICTURE	QTY	DESCRIPTION	PICTURE	QTY	DESCRIPTION	PICTURE	QTY	DESCRIPTION				
1" flat head screw	6	1" Flat Head Screw for Carcass	Bumper	2	Bumper							
Cleat	14	Cleat	3/4" round head screw	2	3/4" Round Head Screw							
9/16" round head screw	56	9/16" Round Head Screw	1 1/2" hinge	2	1 1/2" Softclose Hinge							
	8	Shelf Clip										

## INSTRUCTIONS FOR: WRC2430 / WRC3018



#### [ ASSEMBLY INSTRUCTIONS ]

#### Getting Started:

Prepare protection layer/screwdriver/micro pin-nail. Apply glue&micro pin-nail to joint as needed.

STEP 1: Joint side panel with back panel

STEP 2: Joint top panel with side panel

STEP 3: Joint bottom panel with side panel


STEP 4: Attach the wine rack on the both side

STEP 5: Attach front face frame on

NO.	DESCRIPTION	QTY
А	Back Panel	1
В	Side Panel	2
С	Top&Bottom Panel	2
D	Wine Rack	2
E	Face Frame	1

HARDWARE L	HARDWARE LISTS											
PICTURE	QTY	DESCRIPTION	PICTURE	QTY	DESCRIPTION	PICTURE	QTY	DESCRIPTION				
1" flat head screw	12	1" Flat Head Screw for Carcass										
Cleaf	19	Cleat										
9/16" round head screw	48	9/16" Round Head Screw										

# INSTRUCTIONS FOR: 3DB12 / 3DB15 / 3DB18 / 3DB21 / 3DB24 / 3DB30 / 3DB36 3VDB12 / 3VDB15 / 3VDB18



#### [ ASSEMBLY INSTRUCTIONS ]

#### Getting Started:


Prepare protection layer/screwdriver/micro pin-nail. Apply glue&micro pin-nail to joint as needed.

- STEP 1: Joint side panel with back panel
- STEP 2: Joint bottom panel with side panel
- STEP 3: Joint side panel with bottom & back panel
- STEP 4: Attach frame on and toekick board
- STEP 5: Joint the drawer together, then install the drawer guide.
- STEP 6: Attach the metal triangle on the top corner and put on the adjustable shelf
- STEP 7: Fix drawer head on the drawer front and adjust the cover-space

#### PARTS LISTS NO. DESCRIPTION QTY A Back Panel 1 В Side Panel 2 С Top&Bottom Panel 1 D Toe Kick 1 Ε 1 Face Frame F. 6 Drawer Box Front&Back G Drawer Box Side 6 Н Drawer Box Bottom 3 Drawer Head

23						1 1			
HARDWARE LISTS									
PICTURE	QTY	DESCRIPTION	PICTURE	QTY	DESCRIPTION	PICTURE	QTY	DESCRIPTION	
1" flat head screw	8	1" Flat Head Screw for Metal Triangle	Cleaf	10	Cleat	1" round head screw	12	1" Round Head Screw	
	4	Metal Triangle	9/16" round head screw	40	9/16" Round Head Screw	Burper	12	Bumper	
1" flat head screw	2	1" Flat Head Screw for Carcass	Selfaces slider	3	21" Selfclose Slide				

## INSTRUCTIONS FOR: B12/B15/B18/B21



#### [ ASSEMBLY INSTRUCTIONS ]

#### Getting Started:


Prepare protection layer/screwdriver/micro pin-nail.
Apply glue&micro pin-nail to joint as needed.

- STEP 1: Joint side panel with back panel
- STEP 2: Joint bottom panel with side panel
- STEP 3: Joint side panel with bottom & back panel
- STEP 4: Attach frame on and toekick board
- STEP 5: Joint the drawer together, then install the drawer guide.
- STEP 6: Attach the metal angle on the top corner and put on the adjustable shelf
- STEP 7: Fix drawer head on the drawer front, attach door onto the frame and adjust the cover-space

		7/
NO.	DESCRIPTION	QTY
Α	Back Panel	1
В	Side Panel	2
С	Top&Bottom Panel	1
D	Toe Kick	1
E,	Face Frame	1
F	Drawer Box Front&Back	2
G	Drawer Box Side	2
Н	Drawer Box Bottom	1
1	Adjustable Shelf	1
J	Drawer Head	1
K	Cabinet Doors	1

						IX.	Capillet D	0013			
HARDWARE L	HARDWARE LISTS										
PICTURE	QTY	DESCRIPTION	PICTURE	QTY	DESCRIPTION	PICTURE	QTY	DESCRIPTION			
1" flat head screw	8	1" Flat Head Screw for Metal Triangle	9/16" round head screw	40	9/16" Round Head Screw	Bumper	6	Bumper			
	4	Metal Triangle		4	Shelf Clip	3/4" round head screw	2	3/4" Round Head Screw			
1" flat head screw	2	1" Flat Head Screw for Carcass	Tation size	1	Selfclose Slider	1.1/2" hinge	2	1 1/2" Softclose Hinge			
(S) (S) (Clear	10	Cleat	1" round head screw	4	1" Round Head Screw						

#### INSTRUCTIONS FOR: B24 / B27 /



#### [ ASSEMBLY INSTRUCTIONS ]

#### Getting Started:

Prepare protection layer/screwdriver/micro pin-nail. Apply glue&micro pin-nail to joint as needed.

STEP 1: Joint side panel with back panel

STEP 2: Joint bottom panel with side panel

STEP 3: Joint side panel with bottom & back panel

STEP 4: Attach frame on and toekick board

STEP 5: Joint the drawer together, then install the drawer guide.


STEP 6: Attach the metal triangle on the top corner and put on the adjustable shelf

STEP 7: Fix drawer head on the drawer front, attach door onto the frame and adjust the cover-space

PARIS L	1515	
NO.	DESCRIPTION	QTY
Α	Back Panel	1
В	Side Panel	2
С	Top&Bottom Panel	1
D	Toe Kick	1
Е	Face Frame	1
F	Drawer Box Front&Back	2
G	Drawer Box Side	2
Н	Drawer Box Bottom	1
ı	Adjustable Shelf	1
J	Drawer Head	1
K	Cabinet Doors	2

HARDWARE L	HARDWARE LISTS									
PICTURE	QTY	DESCRIPTION	PICTURE	QTY	DESCRIPTION	PICTURE	QTY	DESCRIPTION		
1" flat head screw	8	1" Flat Head Screw for Metal Triangle	9/16" round head screw	44	9/16" Round Head Screw	Bumper	8	Bumper		
	4	Metal Triangle		4	Shelf Clip	3/4" round head screw	4	3/4" Round Head Screw		
1"flat head screw	3	1" Flat Head Screw for Carcass	Taking day	1	Selfclose Slider	© 1 1/2" hinge	4	1 1/2" Softclose Hinge		
(S) (S) (C) (C) (C) (C) (C) (C) (C) (C) (C) (C	11	Cleat	1" round head screw	4	1" Round Head Screw					

## INSTRUCTIONS FOR:



#### [ ASSEMBLY INSTRUCTIONS ]

#### Getting Started:

Prepare protection layer/screwdriver/micro pin-nail. Apply glue&micro pin-nail to joint as needed.

STEP 1: Joint side panel with back panel

STEP 2: Joint bottom panel with side panel

STEP 3: Joint side panel with bottom&back panel

STEP 4: Attach frame on and toekick board


STEP 5: Attach the metal triangle on the top corner

STEP 6: Attach door onto the frame and adjust the cover-space

NO.	DESCRIPTION	QTY
Α	Back Panel	1
В	Side Panel	2
С	Top&Bottom Panel	1
D	Face Frame	1
E	Toe Kick	1
F	Cabinet Doors	1
		- V 0

HARDWARE L	HARDWARE LISTS									
PICTURE	QTY	DESCRIPTION	PICTURE	QTY	DESCRIPTION	PICTURE	QTY	DESCRIPTION		
1" flat head screw	8	1" Flat Head Screw for Metal Triangle	9/16" round head screw	40	9/16" Round Head Screw					
	4	Metal Triangle	Bumper	2	Bumper					
1" flat head screw	2	1" Flat Head Screw for Carcass	3/4" round head screw	2	3/4" Round Head Screw					
© © Cleat	10	Cleat	1 1/2" hinge	2	1 1/2" Softclose Hinge					

# INSTRUCTIONS FOR: DCW2430 / DCW2436 / DCW2442 DCW2430GD / DCW2436GD / DCW2442GD



#### [ ASSEMBLY INSTRUCTIONS ]

#### Getting Started:

Prepare protection layer/screwdriver/micro pin-nail. Apply glue&micro pin-nail to joint as needed.

STEP 1: Joint side panel with front face frame

STEP 2: Attach top panel with front face frame and side panel

STEP 3: Attach top panel with front face frame and side panel

STEP 4: Attach back panel on side panel


STEP 5: Insert back panel through groove, then screw up

STEP 6: Attach door onto front face frame and adjust the cover-space

NO.	NO. DESCRIPTION				
Α	Face Frame	1			
В	Side Panel	2			
С	Top&Bottom Panel	2			
D	Back Panel	2			
E	Back Panel	1			
F	F Adjustable Shelf				
G	Cabinet Doors	1			

HARDWARE L	HARDWARE LISTS									
PICTURE	QTY	DESCRIPTION	PICTURE	QTY	DESCRIPTION	PICTURE	QTY	DESCRIPTION		
135° angle	2	135 Degree Angle		10	Shelf Clip					
1° flat head screw	6	1" Flat Head Screw for Carcass	Bumper	2	Bumper					
Cleat	22	Cleat	3/4" round head screw	2	3/4" Round Head Screw					
3/4" round head screw	92	9/16" Round Head Screw	1 1/2" hinge	2	1 1/2" Softclose Hinge					

## INSTRUCTIONS FOR: LSB33 / LSB36



#### [ ASSEMBLY INSTRUCTIONS ]

#### Getting Started:

10

11

Prepare protection layer/screwdriver/micro pin-nail. Apply glue&micro pin-nail to joint as needed.

STEP 1: Joint right side panel with right back panel

STEP 2: Fix the bottom panel on

STEP 3: Joint left side panel with left back panel

STEP 4: Attach toekick on

STEP 5: Stand Cabinet Up

STEP 6: Attach face fram(long&short) together, then attach to side&bottom panels

STEP 7: Attach top cross brace using screws

STEP 8: Insert back panel through the groove

STEP 9: Install the metal triangle

Toe Kick


Cabinet Doors

STEP 10: Attach door onto the face frame and adjust the cover-space

PARTS LIS	STS	
NO.	DESCRIPTION	QTY
1	Face Frame	1
2	Face Frame	1
3	Back Panel	1
4	Back Panel	2
5	Adjustable Shelf	1
6	Top&Bottom Panel	1
7	Connect Strip	1
8	Side Panel	2
9	Toe Kick	1

HARDWARE L	HARDWARE LISTS									
PICTURE	QTY	DESCRIPTION	PICTURE	QTY	DESCRIPTION	PICTURE	QTY	DESCRIPTION		
1" flat head screw	8	1" Flat Head Screw for Metal Triangle	Cles. snc Buchla	17	Cleat & Buckle	165° Naga	2	165 Degree Hinge		
	4	Metal Triangle	Dowel	6	Dowel	Bumper	4	Bumper		
	1	Buckle	9/16" round head screw	88	9/16" Round Head Screw	3/4" round head screw	8	3/4" Round Head Screw		
1" flat head screw	11	1" Flat Head Screw for Carcass		6	Shelf Clip	No. 10 to 10	2	1 1/2" Softclose Hinge		

### INSTRUCTIONS FOR: VSD36 / VSD42 / VSD48



### [ ASSEMBLY INSTRUCTIONS ]

#### Getting Started:


Prepare protection layer/screwdriver/micro pin-nail. Apply glue&micro pin-nail to joint as needed.

- STEP 1: Joint side panel with back panel
- STEP 2: Joint bottom panel withe side panel
- STEP 3: Joint side panel with bottom&back panel
- STEP 4: Attach frame on and toekick board
- STEP 5: Joint the drawer together, the install the drawer guide
- STEP 6: Attach the metal triangle on top corner
- STEP 7: Attach drawer head on the drawer front and attach door onto the frame and adjust the cover-space

#### PARTS LISTS DESCRIPTION NO. QTY Α Back Panel 1 В Side Panel 2 Top&Bottom Panel C 1 D Toe Kick 1 E Face Frame 1 F 4 Drawer Box Front&Back 4 G Drawer Box Side Н 2 Drawer Box Bottom 2 Drawer Head Drawer Head 1 J K Cabinet Doors

HARDWARE L	HARDWARE LISTS										
PICTURE	QTY	DESCRIPTION	PICTURE	QTY	DESCRIPTION	PICTURE	QTY	DESCRIPTION			
1" flat head screw	8	1" Flat Head Screw for Metal Triangle	9/16" round head screw	44	9/16" Round Head Screw	3/4" round head screw	4	3/4" Round Head Screw			
	4	Metal Triangle	Taktion site	2	Selfclose Slider	1 1/2" hinge	4	1 1/2" Softclose Hinge			
1" flat head screw	5	1" Flat Head Screw for Carcass	1" round head screw	8	1" Round Head Screw						
(S) (S) (C) (C) (C) (C) (C) (C) (C) (C) (C) (C	11	Cleat	Bumper	12	Bumper						

## INSTRUCTIONS FOR: CSB36



#### [ ASSEMBLY INSTRUCTIONS ]

#### Getting Started:

Prepare protection layer/screwdriver/micro pin-nail. Apply glue&micro pin-nail to joint as needed.

STEP 1: Joint left side panel with left side pack panel

STEP 2: Fix the bottom panel on

STEP 3: Insert back panel through the groove

STEP 4: Attach face frame, then screw up

STEP 5: Joint right side panel with right side pack panel

STEP 6: Attach toekick on

STEP 7: Install metal triangle


STEP 8: Fix drawer head on the drawer front and

attach door onto the frame&adjust the cover-space

NO.	DESCRIPTION	QTY			
Α	Side Panel	2			
В	Side Pack	2			
С	Bottom Panel	1			
D	Toekick	1			
E	Face Frame	1			
F	Back Panel	1			
G	G Drawer Head				
Н	Cabinet Doors	1			

								20 2	
HARDWARE L	HARDWARE LISTS								
PICTURE	QTY	DESCRIPTION	PICTURE	QTY	DESCRIPTION	PICTURE	QTY	DESCRIPTION	
9/16" flat head screw	16	9/16" Flat Head Screw	9/16" round head screw	64	9/16" Round Head Screw	3/4" round head screw	4	3/4" Round Head Screw	
	4	Metal Triangle	© © Cleat	16	Cleat				
1" flat head screw	14	1" Flat Head Screw for Carcass	1 1/2" hinge	4	1 1/2" Softclose Hinge				
135° angle	4	135 Degree Angle	Bumper	4	Bumper				

## INSTRUCTIONS FOR: B12/B15/B18/B21



#### [ ASSEMBLY INSTRUCTIONS ]

#### Getting Started:

Prepare protection layer/screwdriver/micro pin-nail.
Apply glue&micro pin-nail to joint as needed.

- STEP 1: Joint side panel with back panel
- STEP 2: Joint bottom panel with side panel
- STEP 3: Joint side panel with bottom & back panel
- STEP 4: Attach frame on and toekick board
- STEP 5: Joint the drawer together, then install the drawer guide.
- STEP 6: Attach the metal angle on the top corner and put on the adjustable shelf
- STEP 7: Fix drawer head on the drawer front, attach door onto the frame and adjust the cover-space

NO.	DESCRIPTION	QTY	
Α	Back Panel	1 2 1 1	
В	Side Panel		
С	Top&Bottom Panel		
D	Toe Kick		
E F G H I	Face Frame	1	
	Drawer Box Front&Back	2	
	Drawer Box Side	2	
	Drawer Box Bottom	1	
	Adjustable Shelf	1	
	Drawer Head	1	
K	Cabinet Doors	1	

								- 1 T
HARDWARE LISTS								
PICTURE	QTY	DESCRIPTION	PICTURE	QTY	DESCRIPTION	PICTURE	QTY	DESCRIPTION
1° flat head screw	8	1" Flat Head Screw for Metal Triangle	9/16" round head screw	40	9/16" Round Head Screw	Bumper	6	Bumper
	4	Metal Triangle		4	Shelf Clip	3/4" round head screw	2	3/4" Round Head Screw
1° flat head screw	2	1" Flat Head Screw for Carcass	Francisco deter	1	Selfclose Slider	1.1/2" hings	2	1 1/2" Softclose Hinge
© © Cleat	10	Cleat	1" round head screw	4	1" Round Head Screw			